


# RENIX. TYPE CONNECTION.



\* - the colors of RENIX emulator wires may be different depending on different manufacturers.

**In case there are two separate control wires from the petrol ECU  
(i.e. resistance measured between control wires  $\neq 0$ )**

**use separate RENIX emulator for each control wire as shown in diagram.**

Choose “RENIX” type injection in controller configuration program.

**For older controllers (up to version 1.10) order "RENIX" type controller. In controller configuration program set "0" under "cylinder switchover".**